PXI-2599 Features



Contents

PXI-2599 Overview

PXI-2599 Pinout





Table 1. Signal Descriptions

Signal	Description
COM <i>x</i>	Routing destination for corresponding signal connections
NC x	Normally closed signal connection
NO x	Normally open signal connection


PXI-2599 Hardware Diagram



PXI-2599 Topology

Module software name: 2599/2-SPDT (NISWITCH_TOPOLOGY_2599_2_SPDT)

2-SPDT Multiplexer



Making a Connection

You can control the channels using the niSwitch Connect Channels VI or the niSwitch Connect function.

For example, to connect the NO terminal of channel 1 to the COM terminal of channel 1, call niSwitch_Connect (vi, "no1", "com1"). If you now want to connect NC1 to COM1, first disconnect the existing connection. The sequence of calls for this task is as follows:

```
niSwitch_Disconnect(vi, "no1", "com1")

niSwitch_Connect(vi, "nc1", "com1")
```



Note niSwitch_Disconnect(vi, "no1", "com1") does not operate the relay until the niSwitch Connect(vi, "nc1", "com1") is executed.



Note For an initial connection, you do not need to disconnect the default channel (ncx) from COM after the module has been reset or a call to the niSwitch Disconnect All Channels VI or the niSwitch DisconnectAll function has been made.

When scanning the module, a typical scan list entry could be nc1->com1;. This entry routes the signal connected to NC1 to COM1.